

# OEL Recommended Spare Parts List

C3520MFP/C3530MFP/MC350/MC360



Revision 14a

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
						per 500	per 1000	per 2000			
	PX732MFP Scanner (L)	1	43725201	ADF Unit_732Scanner	1	1	2	4	35-00120-01A		-
13	PX732MFP Scanner (L)	2	43725301	Flatbed Unit_732Scanner	1	1	2	4	35-00120-10A, C3520MFP/C3530MFP		-
13	PX732MFP Scanner (L)	2	43725304	Flatbed Unit_732Scanner	1	1	2	4	35-00120-30A, MC350/MC360		-
	ADF Unit	1	43725401	Paper-Tray Assy_732Scanner	1	1	2	4	35-00120-02A		-
	ADF Unit	2	43725501	Pad up Assy_732Scanner	1	1	2	4	35-00120-06A		-
	ADF Unit	3	43725601	ADF PCBA_732Scanner	1	2	4	8	35-00120-07A		-
	ADF Unit	4	43725701	ADF Hinge_732Scanner	2	1	2	4	35-00120-09A		-
10	ADF Unit	5	44254001	ASSY ADF WINDOW_732Scanner	1	1	2	4	52-05169-00A		-
	Flatbed Unit	1	43725801	OP Panel Assy_732Scanner	1	1	2	4	35-00120-13A		-
	Flatbed Unit	2	43725901	OP Panel PCBA_732Scanner	1	2	4	8	35-00120-14A		-
13	Flatbed Unit	3	43726001	Main-PCBA_732Scanner	1	2	4	8	35-00120-00A, C3520MFP/C3530MFP		-
13	Flatbed Unit	3	43726002	Main-PCBA_732Scanner	1	2	4	8	35-00120-31A, MC350/MC360		-
	Flatbed Unit	4	43726101	USB-Board_732Scanner	1	2	4	8	35-00120-16A		-
8	Flatbed Unit	5	44070601	Fan Assy_732Scanner	1	2	4	8	20-01739-00A		-
	Printer NIP-PX732MFP	2	43208104	Frame-Assy. -OP (PX732MFP)	1	1	2	4			-
	Printer NIP-PX732MFP	13	43192101	Frame Assy-Base (PX732)	1	2	4	8			-
	Printer NIP-PX732MFP	14	43192601	Cassette-Assy	1	1	2	4			-
	Printer NIP-PX732MFP	15	42088801	Frame-Separation-Assy.	1	3	6	12			-
	Printer NIP-PX732MFP	16	42089001	Spring-Separation	1	3	6	12			-
13	Printer NIP-PX732MFP	17	43194101	Plate Assy-Side-R (PX732n)	1	2	4	8	C3530MFP/MC360		-
13	Printer NIP-PX732MFP	17	43194102	Plate Assy-Side-R (PX732Ln)	1	2	4	8	C3520MFP/MC350		-
	Printer NIP-PX732MFP	18	43200101	Plate Assy-Side-L (PX732)	1	2	4	8			-
	Printer NIP-PX732MFP	19	43362202	ACINLET-MFP-SW-JST3P	1	1	2	4	ACINLET-SWCord		-
	Printer NIP-PX732MFP	21	43361901	CONN Cord-HRS12P-JST3P-MOLEX10P	1	1	2	4	HeaterAC/IFCord		-
	Printer NIP-PX732MFP	22	42062401	Gear-Idle-Belt (Z20-121)	1	1	2	4			-
13	Printer NIP-PX732MFP	23	43206101	Eject Assy. (PX732)	1	2	4	8	C3530MFP/MC360		-
13	Printer NIP-PX732MFP	23	43206102	Eject Assy. (PX732Ln)	1	2	4	8	C3520MFP/MC350		-
	Printer NIP-PX732MFP	24	43204101	Sensor Assy. -Color-Regist (PX732)	1	2	4	8			-
	Printer NIP-PX732MFP	25	2381028P0032	SMCD-17-210BD(1.0)	1	2	4	8	RearSensor_FFC		-
	Printer NIP-PX732MFP	26	43214301	Spring-Torsion(L)	1	1	2	4			-
	Printer NIP-PX732MFP	27	43214401	Spring-Torsion(R)	1	1	2	4			-
	Printer NIP-PX732MFP	28	43207401	Shaft-Liftup	1	1	2	4			-
	Printer NIP-PX732MFP	29	42060701	Bush	1	1	2	4			-
	Printer NIP-PX732MFP	30	42066701	Gear-Planet-UP-L	1	1	2	4			-
	Printer NIP-PX732MFP	33	43209301	Feeder-Assy. -Regist	1	2	4	8			-
	Printer NIP-PX732MFP	34	43035201	PWR unit-High Voltage Purchase spec.	1	2	4	8	HighVoltage		-
	Printer NIP-PX732MFP	35	2381028P0034	SMCD-12-180BD(1.0)	1	2	4	8	HighVoltage_FFC		-
	Printer NIP-PX732MFP	36	43966401	PWR unit-ACDC Switch	1	2	4	8	200V		-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
						per 500	per 1000	per 2000			
	Printer NIP-PX732MFP	37	43198901	Motor-FAN (80)	1	1	2	4	FUSER		-
	Printer NIP-PX732MFP	40	43215201	Cover-Rear	1	1	2	4			-
	Printer NIP-PX732MFP	41	43215301	Cover-FaceUP	1	1	2	4			-
	Printer NIP-PX732MFP	42	43215401	Cover-FaceUP-Sub	1	1	2	4			-
	Printer NIP-PX732MFP	43	43421701	Cover-Side-R (MFP)	1	1	2	4			-
	Printer NIP-PX732MFP	44	43421601	Cover-Side-L (MFP)	1	1	2	4			-
	Printer NIP-PX732MFP	45	43209201	Cover-Front	1	1	2	4			-
13	Printer NIP-PX732MFP	46	43210701	Cover-Assy. -ManualFeed	1	1	2	4	C3530MFP ODA, OEL, AOS/MC360		-
	Printer NIP-PX732MFP	47	43324601	Lever-Assy. -Front-Lock	1	1	2	4	600DPI		-
	Printer NIP-PX732MFP	48	43295201	LED Head Unit-51STA	4	2	4	8			-
	Printer NIP-PX732MFP	56	43215701	Cover-Rear-Bottom	1	1	2	4			-
	Printer NIP-PX732MFP	63	43420302	Stay-Guide-L-Assy (L)	1	1	2	4			-
	Printer NIP-PX732MFP	64	43422201	Stay-Guide-R-Assy	1	1	2	4			-
	Printer NIP-PX732MFP	65	43421001	Stay-Arm-L	1	1	2	4			-
	Printer NIP-PX732MFP	66	43421501	Stay-Arm-R	1	1	2	4			-
	Printer NIP-PX732MFP	67	43700301	Shield-Clamp	1	1	2	4			-
	Printer NIP-PX732MFP	68	43700501	Shield-Clamp-Base	1	1	2	4			-
8	Printer NIP-PX732MFP	69	43540701	Guide-Cable	1	1	2	4			-
13	Cover-Assy. -Top	2	43214801	Lever-Stack-L	1	1	2	4	C3530MFP/MC360		-
13	Cover-Assy. -Top	3	43214901	Lever-Stack-R	1	1	2	4	C3530MFP/MC360		-
	Cover-Assy. -Top	6	43508801	RFID-UNIT Assy. - (Maintenance)	1	2	4	8	Board-RFIDR/W, Concurrent ; a, b, c		-
	Cover-Assy. -Top	11	43212901	Holder-Head (SH)	4	1	2	4			-
	Cover-Assy. -Top	12	43213001	Plate-FG-Head-L (SH)	4	1	2	4			-
	Cover-Assy. -Top	13	43213101	Plate-FG-Head-R (SH)	4	1	2	4			-
	Cover-Assy. -Top	15	43501005	Push-Nut (SPN-2.6 A. C. P)	8	1	2	4			-
	Cover-Assy. -Top	16	43213301	Cable-Assy. -Head	1	1	2	4	LED-HEAD-FFC RFID-FFC		-
	Cover-Assy. -Top	17	43214001	Cover-Top	1	1	2	4			-
	Cover-Assy. -Top	18	43214101	Cover-Top (Sub)	1	1	2	4			-
	Cover-Assy. -Top	20	43214501	Cover-Hinge (L)	1	1	2	4			-
	Cover-Assy. -Top	21	43214601	Cover-Hinge (R)	1	1	2	4			-
	Cover-Assy. -Top	27	43551301	Link-Arm	1	1	2	4			-
	Cover-Assy. -Top	28	43420001	Link-Head	1	1	2	4			-
	Cover-Assy. -Top	29	43420101	Holder-Post	2	1	2	4			-
	Frame-Assy-OP (PX732MFP)	3	43208601	Button-Lock	1	1	2	4			-
	Frame-Assy-OP (PX732MFP)	4	43421901	Cover-Op-Pannel (MFP)	1	1	2	4			-
	Frame-Assy-OP (PX732MFP)	5	43198801	Spring-Torsion (FG)	1	1	2	4			-
	Frame-Assy-OP (PX732MFP)	6	42067801	Spring-Compression (Lock)	1	1	2	4			-
	Board-Assy-CUPU	1	43567302	M32-2 PCB-Assy. Maintenance Spec.	1	2	4	8	C3530MFP		-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks For environment
						per 500	per 1000	per 2000			
	Board-Assy-CUPU	1	43567303	M32-3 PCB-Assy. Maintenance Spec.	1	2	4	8	C3520MFP		-
13	Board-Assy-CUPU	1	43567304	M32-4 PCB-Assy. Maintenance Spec.	1	2	4	8	MC360		
13	Board-Assy-CUPU	1	43567307	M32-7 PCB-Assy. Maintenance Spec.	1	2	4	8	MC350		
14	Board-Assy-CUPU	2	44510001	Board-FX1 maintenance specification	1	2	4	8	C3530MFP	A	-
14	Board-Assy-CUPU	2	44550801	Board-FX3 maintenance specification	1	2	4	8	MC360	A	-
13	Board-Assy-CUPU	3	43577901	Plate-ShieldCU-(MFP)	1	1	2	4	C3530MFP/MC360		-
13	Board-Assy-CUPU	3	43577902	Plate-ShieldCU-(MFP)	1	1	2	4	C3520MFP/MC350		-
	Board-Assy-CUPU	4	43586201	CONN Cord-FLEXY-732MFP FAX	1	2	4	8	C3530MFP		-
13	Board-Assy-CUPU	4	44297901	CONN Cord-FLEXY-732MFP-MLK FAX	1	2	4	8	MC360		-
	Stay-Guide-R-Assy	1	43421201	Plate-Stay-Guide-R (Caulking)	1	1	2	4			-
	Stay-Guide-R-Assy	2	43500301	Lever-Lock	1	1	2	4			-
	Stay-Guide-R-Assy	3	43481501	SP-Lock-R	1	1	2	4			-
	Stay-Guide-R-Assy	4	43430101	Rail-Stay-R	1	1	2	4			-
	Stay-Guide-L-Assy	1	43420401	Plate-Stay-Guide-L(Caulking)	1	1	2	4			-
	Stay-Guide-L-Assy	2	43500301	Lever-Lock	1	1	2	4			-
	Stay-Guide-L-Assy	3	43481401	SP-Lock-L	1	1	2	4			-
	Stay-Guide-L-Assy	4	43430001	Rail-Stay-L	1	1	2	4			-
	Stay-Guide-L-Assy	5	43657601	Shield-Cable	1	1	2	4			-
	Stay-Guide-L-Assy	6	43657501	Shield-Drawer-L	1	1	2	4			-
	Stay-Guide-L-Assy	7	2201000P0301	9714N-30Z03-G4C	1	1	2	4			-
	Stay-Guide-L-Assy	8	43497603	Screw-Shoulder	2	1	2	4			-
	Stay-Guide-L-Assy	9	43459103	CONN Cord-Wire Power2	1	2	4	8			-
	Stay-Guide-L-Assy	10	43459102	CONN Cord-Wire Signal	1	2	4	8			-
	Stay-Guide-L-Assy	11	43700201	Shield-Cable-Outer	1	1	2	4			-
	Feeder-Assy. -Regist	8	43135401	OR-Board-MIP	1	2	4	8	Board-FrontSensor		-
	Feeder-Assy. -Regist	10	43361401	CONN Cord-AMP5P-AMP5P	1	1	2	4	FrontSensorCord		-
	Feeder-Assy. -Regist	11	43209601	Cover-SNS	1	1	2	4			-
	Plate Assy-Side R	4	43614901	OR-Board-PRS	1	2	4	8	Board-TonerSensor		-
	Plate Assy-Side R	5	2381028P0030	SMCD-10-280BD(1.0)	1	2	4	8	TonerSensor_FFC		-
	Plate Assy-Side R	7	43195101	Motor-DC-ID-M58	1	1	2	4			-
	Plate Assy-Side R	8	43361601	CONN Cord-AMP10P-AMP10P	1	1	2	4	DC-ID MotorCord		-
	Plate Assy-Side R	9	43353101	OR-Motor-Pulse-Liftup	1	1	2	4			-
	Plate Assy-Side R	10	43195501	Bracket-Inner(Caulking)	1	1	2	4			-
	Plate Assy-Side R	11	43196201	Gear Assy. -Planet	1	1	2	4	Surrounding of Fuser		-
	Plate Assy-Side R	12	43196601	Gear-Idle-Heat(Z14-102)	1	1	2	4	Surrounding of Fuser		-
	Plate Assy-Side R	13	43196701	Gear-Idle-Z35	1	1	2	4	Surrounding of Fuser		-
	Plate Assy-Side R	19	43353001	OR-Motor-Pulse-HOP	1	1	2	4			-
	Plate Assy-Side R	20	43361501	CONN Cord-AMP4P-AMP4P	1	1	2	4	HoppingMotorCord		-

Rev	Unit Name	No.	Part No.	Part Name	Q'ty /Unit	Recommended Q'ty/Year			Remarks	Del/ Add	ks for environment
						per 500	per 1000	per 2000			
	Plate Assy-Side R	21	42058303	Solenoid	1	1	2	4			-
13	Plate Assy-Side R	23	43197801	Motor-Pulse-Fuser	1	1	2	4	C3530MFP/MC360		-
13	Plate Assy-Side R	23	43352101	OR-Motor-Pluse-Fuser	1	1	2	4	C3520MFP/MC350		-
13	Plate Assy-Side R	24	43362301	CONN Cord-JST4P-JST4P	1	1	2	4	C3520MFP/MC350 HeaterMotorCord		-
	Plate Assy-Side R	37	1051002C0002	TR-14.5-10-8	1	1	2	4	Toroidalcore		-
	Plate Assy-Side L	2	43352901	OR-Motor-Pulse-Belt	1	1	2	4			-
	Plate Assy-Side L	4	43415601	Microswitch Assy. -PX732	1	2	4	8	CoverOpenSwitchAssy		-
	Plate Assy-Side L	5	43201001	Link-LiftUp-L	1	1	2	4			-
	Plate Assy-Side L	7	43361502	CONN Cord-AMP4P-AMP4P	1	1	2	4	BeltMotorCord		-
	Sensor Assy. - Color	2	43135301	OR-Board-ZAK	1	2	4	8	Board-RearSensor		-
	Sensor Assy. - Color	4	5654200P0001	GP2TC2J0000F	1	3	6	12	DensitySensor		-
	Sensor Assy. - Color	5	43361701	CONN Cord-MOLEX5P-MOLEX5P	1	1	2	4	DensitySensorCord		-
	Frame Assy-Base (PX732)	11	43334801	Roller Assy. -Sub	1	1	2	4			-
	Frame Assy-Base (PX732)	23	43334901	Roller Assy. -Hopping	1	1	2	4			-
	Eject Assy.	1	43206301	Guide-Eject-Lower	1	1	2	4			-
	Eject Assy.	2	43206401	Lever-Eject-Sensor	1	1	2	4			-
	Eject Assy.	4	40135301	Photo-Interrupter	1	1	2	4	ExitSensor		-
	Eject Assy.	5	43361801	CONN Cord-AMP3P-AMP3P	1	1	2	4	ExitSensorCord		-
	Eject Assy.	6	43206601	Guide-Eject-Upper	1	1	2	4			-
	Eject Assy.	7	43206801	Spring-Torsion-Eject	7	1	2	4			-
	Eject Assy.	8	43222001	Roller-BIAS-FU	5	1	2	4			-
	Eject Assy.	9	43222101	Roller-BIAS-FD	2	1	2	4			-
	Eject Assy.	10	43649701	Sponge-Roller-FD	2	1	2	4			-
	Eject Assy.	11	43206901	Shaft Assy. -Eject (FU)	1	1	2	4			-
13	Eject Assy.	12	43207201	Shaft Assy. -Eject (FD)	1	1	2	4	C3530MFP/MC360		-
13	Eject Assy.	12	43207202	Shaft Assy. -Eject (FD)	1	1	2	4	C3520MFP/MC350		-
	Eject Assy.	13	43207301	Gear-Idle-Exit (Z19)	2	1	2	4			-
	Eject Assy.	14	43222601	Bearing-Eject	2	1	2	4			-
	Eject Assy.	15	43222701	Gear-Idle-Exit (Z21)	3	1	2	4			-